

Turning Equipment On

Turn on in any order:

1. Computer
2. VCR
3. Video Projector
4. Sound Amplifier

Switching Between Sources:

(NOTE: VCR runs through Computer. Computer *must* be on to see VCR)

From Computer to VCR:

1. With Projector on “*Computer*,” open application “*Cute! TV USB*” and switch input of application to “*Composite*” with the “**Change Video Source**” button on the application Control Panel window

From VCR to Computer:

1. With Projector on “*Computer*,” close the “*Cute! TV USB*” application

Turning Equipment Off

Turn off in any order:

1. Computer
2. VCR
3. Video Projector
4. Sound Amplifier

In case of emergency, call Media Services at x3295.